

**VRAE**

---

# **Using the VRAE Personal Multigas Monitor**

Firmware v 2.00D



# Training Agenda:

---

- VRAE features
- Turning on the VRAE
- Recommended Daily Start-up Procedure
- User displays
- Alarm modes
- Programming displays
- Calibration



# VRAE Features: Sensors

---

- Oxygen: 0-30%
- Combustibles (Dual Range):
  - ✓ 0-100% by Volume
  - ✓ 0-100% of LEL
- Toxic gas sensors: Select up to four from CO, H<sub>2</sub>S, SO<sub>2</sub>, NO, NO<sub>2</sub>, Cl<sub>2</sub>, ClO<sub>2</sub>, HCN, NH<sub>3</sub>, PH<sub>3</sub>
- LEL/O<sub>2</sub> + 3 Toxics      or      LEL + 4 Toxics
- ClO<sub>2</sub> requires retrofit Teflon tubing inside



# VRAE Features: Reliability

---

- Extremely rugged for extensive field use
- Weather-proof case
- Temperature range of -4°F to 113°F (-20°C to 45°C)
- 4-Way power: NiMH, Alkaline or run continuously on 110 VAC and 12 VDC
- Runs 10 hours continuously
- RFI protection against radio interference
- Intrinsically safe: Class I, Division I, Groups A, B, C, D
- LEL Over-Range Protection



# VRAE Features: Rugged Boot

---

Teflon Probe



Rugged  
Rubber  
Boot




Belt Clip




# VRAE Features: Rugged Case

---



# VRAE Features: Simple Faceplate

---



- Three buttons on a sealed membrane faceplate:
  - ✓ Y/+ : clears & tests alarms
  - ✓ N/- : turns on manual backlight for 90 seconds
  - ✓ ON/MODE

# VRAE Features: Internal Pump

---

- Makes remote sampling easy
- Sample draw over 200 feet horizontally and 90 feet vertically!
- Moisture and dust trap for added protection
- Pump stall feature: when moisture is detected or when pump is blocked the pump will shut off, protecting the VRAE from potential damage
- ~500 cc/min at High flow, ~ 25% less at Low flow. Default is high





# VRAE vs QRAE Plus

---

- Stronger Pump (500 vs. 350 cc/min)
- Firmware & tubing for ClO<sub>2</sub> Sensor
- Better firmware for VOL Sensor
- Up to 4 Toxic Gas Sensors vs. 3
- Different form factor
- Higher price



# VRAE Start-up: Turning On

---

- Unplug VRAE from charger
- Hold “MODE” Key to turn on
- Alarm will beep once
- Watch display screen for messages such as:
  - ✓ Sensors installed & their warranty expiration
  - ✓ Alarm limits
  - ✓ Last calibration date
  - ✓ User/Alarm/Datalog modes
- Warm-up will take approximately 90 seconds



# VRAE Start-up: Warnings

---

TOX1

TOX2

TOX3

LEL

**Incorrect Year  
Check Clock!!!**

OXY

- If this screen appears during the start-up just acknowledge it with the “Y” key and follow the procedure for setting the clock.
- The battery has gone dead and the VRAE has detected a mismatch between the date code on the sensors and its internal clock.



# VRAE Start-up: Warnings

---

TOX1

TOX2

TOX3

LEL

O<sub>2</sub> Installed

Warranty Expired

OXY

- This is a warning screen. As long as the sensor calibrates properly it is valid to continue using it. Acknowledge by pressing the “Y” key to continue warm-up.
- To ensure proper operation, RAE Systems recommends replacing sensors at the end of their warranty period.



# VRAE Start-up: Check Sensor Zero

---

TOX1	TOX2		TOX3	
	0	0	0	
LEL	0	20.9		OXY

- After 90 sec. warm-up, the VRAE should display readings for all of the installed sensors
- If there is no alarm, and the sensor readings are within limits, then the VRAE is ready for use.



# VRAE Start-up: Check Sensor Zero

---

TOX1	TOX2		TOX3
	0	0	0
LEL	0-3	20.6-21.2	
			OXY

- If any reading is outside these limits, wait a few minutes then check again.
  - ✓ If readings are in limits use the unit
  - ✓ If readings are still outside these limits perform "Fresh air calibration"

# VRAE Start-up: Pump Alarm

---

TOX1	TOX2		TOX3
	0	0.0	0
LEL	0	Pump	20.9
			OXY

- Every time the VRAE is used it is important to check pump flow
- Block the filter on the pump inlet
- Reset pump alarm by pressing the “Y” key
- If pump does not go into alarm, check for loose/cracked filter or service pump



## 3 Display Modes

---

- **Program Mode:** 12 screens and programmability for most advanced users
- **Display Mode:** 12 screens, no programmability
- **Text Mode:** 3 screens and has password to get into programming (default)





# Comparison of Display Modes

---

## Program (12)

Sensor ID  
PEAK  
MIN  
STEL  
TWA  
Battery  
Time/Date/Temp  
Start Datalog\*  
LEL Gas  
Pump Speed  
LEL/VOL  
PC Comm

## Display (12)

Sensor ID  
PEAK  
MIN  
STEL  
TWA  
Battery  
Time/Date/Temp  
Start Datalog\*  
LEL Gas  
Pump Speed  
LEL/VOL  
PC Comm

## Text (3)

Battery  
PC Comm  
Sensor ID w/OK

\* Will not show  
if no datalogging  
option or auto  
datalogging



# Instantaneous Reading (Main Display)

---

TOX1	TOX2		TOX3
	0	0	0
LEL	0	OK!	20.9
			OXY

- In text mode, "OK!" is displayed if there is no alarm

# Instantaneous Reading (Main Display)

---

TOX1

TOX2

TOX3

LEL

CO

LEL

SO<sub>2</sub>

H<sub>2</sub>S

OXY

OXY

- CO: Carbon Monoxide sensor
- SO<sub>2</sub>: Sulfur Dioxide sensor
- H<sub>2</sub>S: Hydrogen Sulfide sensor
- LEL: Combustible gas sensor
- OXY: Oxygen sensor
- Tap "MODE" key to proceed



*This screen is deleted in Text Mode*

## Peak Reading Display

TOX1	TOX2		TOX3
	34	584	11
LEL	6	PEAK	20.9
			OXY

- Holds Highest reading since VRAE was turned on or Peak cleared
- Tap "MODE" key to proceed to next screen



*This screen is deleted in Text Mode*

## Minimum Reading Display

TOX1	TOX2		TOX3
	0	0.0	0
LEL	0	MIN	13.5
			OXY

- Holds Lowest reading since VRAE was turned on or Min cleared
- Tap "MODE" key to proceed to next screen



*This screen is deleted in Text Mode*

## STEL Display

TOX1	TOX2	TOX3
0	0.0	0
LEL	STEL	OXY

- Short Term Exposure Limit (average for the past 15 minutes)
- Displays “\*\*\*\*” until VRAE has been on for 15 minutes
- STEL only is calculated for toxics
- STEL alarm beeps once a second
- Tap “MODE” key to proceed



*This screen is deleted in Text Mode*

## TWA Display

TOX1	TOX2		TOX3
0	0.0	0	
LEL	TWA		OXY

- Time Weighted Average is the accumulated dose in ppm-hours since the VRAE was turned on, divided by 8 hours
- TWA only is calculated for toxics
- TWA alarm beeps once per second
- Tap "MODE" key to proceed to next screen



*This screen is deleted in Text Mode*

## Battery Voltage Display

---

TOX1

TOX2

TOX3

LEL

OXY

Battery = 5.1V  
Shut off at 4.1V

- VRAE shuts down when battery voltage drops below 4.2 volts
- Normal full charge is over 4.8 volts
- Tap “MODE” key to proceed to next screen





*This screen is deleted in Text Mode*

## Date/Time/Run Time/Temp. Display

---

TOX1	TOX2	TOX3
LEL	<div>Feb 15, 01 12:00 ON=01:22 75°F</div>	OXY

- Date, Time of day
- Accumulated time in hours and minutes since the VRAE was turned on
- Temperature in Centigrade or Fahrenheit (operating range -20 to +45°C, -4 to +113°F)
- Tap “MODE” key to proceed



*This screen is deleted in Text Mode*

## Datalog Mode Display

---

TOX1

TOX2

TOX3

LEL

OXY

Start Datalog?

- Manual: logs if “Y/+” key is pushed now
- Automatic: this screen is deleted and it logs data when as soon as the VRAE turns on
- Scheduled: logs data at a preset date & time
- Periodic: start and stop datalogging daily based on preset time



*This screen is deleted in Text Mode*

## Datalog Mode Display

TOX1	TOX2		TOX3
	0	0.0	0
LEL	0	L	20.9
			OXY

- A small “L” displayed in the left center of the screen indicates datalogging is active
- Will datalog 16,000 points (53 hrs of data)
- $T_{max} = (\#Points/\#Sensors) * Sample\ Period$   
 $= (16,000/5) * 60 = 192k\ secs = 53\ hours$
- Entering programming pauses datalogging



*This screen is deleted in Text Mode*

## LEL Units Display

TOX1

TOX2

TOX3

LEL

LEL gas =  
Methane

OXY

- Target Gas for LEL displayed here (VRAE is currently measuring LEL in units of methane)
- Correction Factor can only be changed in programming mode
- Tap "MODE" key to proceed to next screen



*This screen is deleted in Text Mode*

## Pump Speed Display

---

TOX1

TOX2

TOX3

LEL

Pump Speed =  
Low?

OXY

- Low speed flow rate: 300-400 cc/min
- High speed flow rate: 400-500 cc/min
- Tap "MODE" key to proceed to next screen



*This screen is deleted in Text Mode*

## LEL/VOL Display

TOX1

TOX2

TOX3

LEL

LEL/VOL =  
%LEL?

OXY

- % LEL Display – “%LEL?”
- %VOL Display – “%VOL?”
- Auto Ranging Display – “Auto?”
- In Auto Mode, after reaching 100% LEL reading switches to %VOL; then must turn off to re-enter LEL readings
- Tap “MODE” key to proceed



# Communicate with PC Display

---

TOX1

TOX2

TOX3

LEL

Communicate  
with PC?

OXY

- If “Y/+” key is pushed then VRAE will display “Monitor will Pause. OK?”
- If “Y/+” key is pushed again the VRAE will display “Ready...” until it receives a signal from the computer or the “MODE” key is pressed.
- Tap “MODE” key to proceed



# Communicate with PC Display

---

TOX1

TOX2

TOX3

LEL

Ready...

OXY

- ***When the VRAE is in this communication standby mode it stops monitoring gas concentrations and stops datalogging.***
- Datalogging must be manually restarted when exiting unless automatic datalogging is in use.





# VRAE Alarm Signals

---

- The VRAE will provide audible and visual alarms to alert users to unsafe states
- It is extremely important to note that during the following conditions the alarm signals are disabled:
  - ✓ *When entering the “Communicate with PC?” standby mode.*
  - ✓ *When entering the “Calibrate Monitor” menu*
  - ✓ *When viewing data in the “View or Change Datalog?” menu*



## VRAE Alarms: High

TOX1	TOX2		TOX3
	0	High	0
LEL	0		20.9
			OXY

- “High” display along with 3 beeps/second audible/visible alarm and flashing display backlight indicates that TOX2 sensor (SO<sub>2</sub>) has exceeded high alarm setpoint (10 ppm default set point for SO<sub>2</sub>).
- Press “Y/+” key to clear if latching alarm



## VRAE Alarms: Low

---

TOX1	TOX2		TOX3
	0	0	0
LEL	0		Low
			OXY

- “Low” display along with 2 beeps/second audible/visual alarm and flashing display backlight indicates that Oxygen sensor has gone into low alarm (less than 19.5% Oxygen default)
- Press “Y/+” key to clear if latching alarm



## VRAE Alarms: STEL

TOX1	TOX2		TOX3
	0	STEL	0
LEL	0		20.9
			OXY

- “STEL” display along with a 1 beep/second audible/visual alarm indicates that SO2 sensor has exceeded STEL alarm setpoint (5 ppm default)
- ***This alarm will only clear after 15 minutes in clean air or if the VRAE is turned off!***



## VRAE Alarms: TWA

TOX1	TOX2		TOX3
	0	TWA	0
LEL	0		20.9
			OXY

- “TWA” display along with a 1 beep/second audible/visual alarm indicates indicates that SO2 sensor has exceeded the TWA alarm setpoint (2 ppm default)
- ***This alarm will only clear after moving to clean air and then turning off the VRAE***



## Alarms: LEL OFF

---

TOX1	TOX2		TOX3
	0	0	0
LEL	OFF		20.9
			OXY

- “OFF” display along with a 3 beeps/second audible/visual alarm indicates that LEL sensor has been exposed to too much gas and has shut off to protect the sensor.
- Move the meter to clean air and press the “Y” key to reset.

## Alarms: NEG

TOX1	TOX2		TOX3
	0	NEG	0
LEL	0		20.9
			OXY

- “NEG” display along with a 1 beep/second audible/visual alarm indicates indicates that SO<sub>2</sub> sensor has drifted negative (below zero) because the sensor was zeroed in an area containing SO<sub>2</sub>.
- ***Perform “Fresh Air Calibration” in an area clear of all toxics.***



## VRAE Alarms: Pump

TOX1	TOX2		TOX3
	0	0.0	0
LEL	0	Pump	20.9
			OXY

- “Pump” display along with 3 beep audible alarm indicates that pump has stopped due to line clog
- Pump alarm is a latching alarm
- Clear line/filter and press “Y/+” key to clear alarm and restart pump





# VRAE Alarms: Low Battery

TOX1	TOX2		TOX3
	0	0.0	0
LEL	0	Bat	20.9
			OXY

- A flashing “Bat” display along with a 1 beep alarm every 10 seconds indicates that the battery voltage has dropped below 4.35 V and it will shut down in 20-30 minutes
- Quickly complete confined space entry and charge VRAE or install alkaline battery



# VRAE Alarms: Memory Full

---

TOX1	TOX2		TOX3
	0	0.0	0
LEL	0	MEM	20.9
			OXY

- A flashing “MEM” display along with a 1 beep/second audible/tactile/visual alarm indicates that the datalog memory is full.
- Clear datalog in “View or Change Datalog?”

# Getting Into Programming

---

- *Hold “MODE” and “N/-” keys for 5 sec. to get in Programming Mode*
- If VRAE asks a question “?”
  - ✓ Answer “Y” or “N”
- To Accept or Escape
  - ✓ Use “MODE” Key
  - ✓ repeatedly pushing the “MODE” key will always eventually return user to main display



# Programming Menus

---

- Calibrate Monitor?
- Change Alarm Limits?
- View or Change Datalog?
- Change Monitor Setup?
- Change Sensor Configuration?
- *Choose (Y) to accept or (N) to move on*



# Calibrate Monitor?

---

- Fresh Air Calibration?
  - ✓ *Make sure air is clean!*
- VOL% Zero Calibration?
- Multiple Sensor Calibration?
- Single Sensor Calibration?
- Modify Span Gas Value?
- Change LEL/VOL Span Gas?
  - ✓ *Choose (Y) to accept or (N) to move on, MODE to escape*



# Fresh Air Calibration

---

TOX1

TOX2

TOX3

LEL

Fresh Air  
Calib?

OXY

- At “Fresh Air Calibration” press “Y/+” key
- Zero’s all sensors including LEL but not VOL and sets O<sub>2</sub> to 20.9%.
- Press “Y/+” key to continue



# VOL% Zero Calibration

---

TOX1

TOX2

TOX3

LEL

OXY

Zero cal done  
Reading = 0

- At “VOL% Zero Calibration” press “Y/+” key (Only shown in VOL or Auto LEL/VOL Mode)
- Apply VOL zero gas (often pure N<sub>2</sub>)
- Zero’s only VOL sensor, does not affect O<sub>2</sub>
- Successful zero cal appears as screen above
- Press “Y/+” key to continue



# Multiple Sensor Calibration

TOX1	TOX2			TOX3
	CO	- - -	H <sub>2</sub> S	
LEL	LEL	OK?	- - -	OXY

- At “Multiple Sensor Calibration” press “Y/+” key
- For CO/H<sub>2</sub>S/LEL mixed gas calibration the next screen should appear as above



# Multiple Sensor Calibration

---

TOX1

TOX2

TOX3

LEL

OXY

**Apply Mixed Gas**

- Press “Y/+” key to display this screen
- Attach calibration gas regulator to mixed gas cylinder and attach calibration hose to VRAE
- Turn on calibration gas
- Follow instructions on screen



# Multiple Sensor Calibration

---

TOX1

TOX2

TOX3

LEL

OXY

**No Gas Flow...**

- If you get this screen check for gas flow, the VRAE will not perform span calibrations unless it senses calibration gas



# Multiple Sensor Calibration

---

TOX1

TOX2

TOX3

LEL

Apply gas or hit  
any key to start

OXY

- Try again after you have verified that the gas is correct and it is flowing properly
- Follow instructions on screen
- Disconnect regulator from gas cylinder when complete calibration



# Single Sensor Calibration

---

TOX1	TOX2		TOX3
	CO	SO <sub>2</sub>	H <sub>2</sub> S
LEL	LEL	pick	OXY

- Toxic sensors can be calibrated individually if necessary
- At “Single Sensor Calibration” press “Y/+” key
- Use “MODE” to select sensor

# Single Sensor Calibration

---

- Attach calibration gas regulator to calibration gas cylinder
- Attach calibration hose to VRAE and make sure it is tight
- Turn on cal gas (Pre-soak slow sensors)
- With cursor on the appropriate sensor press “Y/+” key
- Follow instructions on screen
- Repeat if necessary for other gases
- Disconnect regulator



# Single Sensor Pre-Soak

- Standard Cal time is 60 sec except for ClO<sub>2</sub>, which is 150 sec
- Some slow sensors require pre-equilibration

Sensor	Response Time $t_{90}$ (seconds)	Total Cal Time (seconds)	Pre-exposure Time for 1-min Cal Time
HCN	200	230	170
ClO <sub>2</sub> , NH <sub>3</sub>	150	150	90
Cl <sub>2</sub> , PH <sub>3</sub>	60	120	60
CO, H <sub>2</sub> S, SO <sub>2</sub> , NO, NO <sub>2</sub> , O <sub>2</sub> , LEL, VOL	≤40	60	0



# Calibration

---

- **Modify Span Value**
  - ✓ Allows you to change the calibration gas values to use other cal gases
  - ✓ Do not change if you are using the RAE Systems cal gas supplied with your meter
- **Change LEL/VOL Span Gas?**
  - ✓ Allows you to change the calibration gas, which by default is methane
  - ✓ Do not change if you are using the RAE Systems cal gas supplied



# Change Alarm Limits?

---

- Change High alarm limit?
  - ✓ 3 Beeps per second (“High”)
- Change Low alarm limit?
  - ✓ 2 Beeps per second (“Low”)
- Change STEL alarm limit?
  - ✓ 1 Beep per second (“STEL”)
- Change TWA alarm limit?
  - ✓ 1 Beep per second (“TWA”)

*Choose (Y) to accept or (N) to move on,  
MODE to escape*





# View or Change Datalog?

---

- Reset Peak and Minimum?
- Clear All Data?
- Change Datalog Period?
- Select Data Type?
- View Datalog?
- Enable/Disable Datalog?

*Choose (Y) to accept or (N) to move on,  
MODE to escape*



# Change Monitor Setup?

---

- Change Site ID?
- Change User ID?
- Change Alarm Mode?
- Change User Mode?
  - ✓ “Program”
  - ✓ “Display”
  - ✓ “Text”



# Change Monitor Setup?

---

- Change Real Time Clock?
- Change Backlight Mode?
- Change Password?
- Change Pump Speed?
- Change Averaging Method?
- Set Temperature Unit? (°C or °F)

*Choose (Y) to accept or (N) to move on  
MODE to escape*



# Change Sensor Configuration?

---

- Change LEL/VOL Sensor Type?
- Enable/Disable Sensor?
- Change Dilution Ratio?
- Change LEL/VOL Gas Selection

*Choose (Y) to accept or (N) to move on,  
MODE to escape*



# VRAE: Power Off

---

- Hold Mode Key for full 5 seconds
- Audible alarm will beep and display will read “Power-down in ...5 seconds”
- Plug 12 VDC charger into VRAE charge port when not in use



# VRAE: Smart Charging

---

TOX1

TOX2

TOX3

LEL

Start Battery  
Deep discharge?

OXY

- NiMH does not need deep discharge
- Full charge can take up to 10 hours
- With the smart charging circuitry, removing the charger is not necessary.

# VRAE: Trickle Charging

---

TOX1

TOX2

TOX3

LEL

Charging.....

Battery=5.9V


OXY

- Turning off and on power to charger will reset charge to high and may burn-out battery if done repeatedly

# VRAE: Alkaline Adapter

---

- Accepts 4 AA alkaline batteries
- Provides 10 hours of operation
- Make sure that cable runs in groove between batteries or it won't fit
- When reattaching VRAE lid, seat it first at back by batteries then push the front down





# Questions?

---

